


Protective sleeves for PE 5, PE 5/T, PE 5/L and PE 5/L-T



- Trap guard to clip in the openings in the protective covers over the lifting plungers of the PE 5, PE 5/T, PE 5/L and PE 5/L-T. Refer to the assembly instructions for the installation dimensions.
- **Note:** Do not walk on the protective covers. Slots for add-on parts must be made by the customer; for details, see assembly instructions

Product description

Assembly, positioning, and orientation


Technical data

No.	Material
3842545965	PA
3842545966	

Accessories

Required accessories


Protective covers for conveyor unit



Protective Covers for ST 5/XH,
ST 5/H

- section center protective cover (**A**)
 - Protective covers for transition between curve (diverter, junction) / conveyor unit (**B**)
 - Protective covers for transition between conveyor unit/conveyor unit with different rollers (**C**)
 - Spring element (**H**), 4x required for each protective cover
-

Ordering codes



Required protective sleeves sets for PE 5, PE 5/T, PE 5/L and PE 5/L-T

b ¹ (mm)	l _{WT} ² (mm)	Quantity	No.	Quantity	No.	Quantity	No.
			A		B for PE 5 and PE 5/L		B for PE 5/T and PE 5/L-T
455	455	1x	3 842 545 965				
455	650	1x	3 842 545 965				
650	650	1x	3 842 545 965				
				+1x		+2x	
650	845	1x	3 842 545 965		3 842 545 966		3 842 545 966
				+3x		+3x	
845	845	1x	3 842 545 965		3 842 545 966		3 842 545 966
				+3x		+3x	
845	1040	1x	3 842 545 965		3 842 545 966		3 842 545 966

1) b = Track width of the positioning unit in the direction of transport

2) l_{WT} = workpiece pallet length

	No.
PE 5 Basic protective sleeve	3842545965
PE 5 protective sleeve	3842545966