



AB 5 to CU 5 connection kit




- The curve is a ready-for-operation module for branching transport of workpiece pallets
- Curves can be driven either on the inside or on the outside. Instead of using an adjacent drive module, the curve can be driven using a drive kit AB 5.
- **Notice:** A connection kit must be ordered for some configurations:
KR = 2; DSM = 2; DST = 2
KR = 2; DSM = 2; DST = 1
KR = 1; DSM = 1; DST = 1
KR = 1; DSM = 1; DST = 2
All other order examples can be assembled with the standard drive kit AB 5 without additional parts.

Fields of application

AB 5 to CU 5 connection kit



Connection kit AB 5 on CU 5 order examples



1) Drive side

* A connection kit is required for this configuration.

Delivery notes

Condition of Delivery

Not assembled

Ordering codes

	No.
AB 5 – CU 5 connection kit	3842562895