


Section connection




- Section link (A)
- Lateral guide (B)

[PDF](#) Section link assembly instructions


[PDF](#) Lateral guide assembly instructions

Product description

Section link



Lateral guide holder



The middle lateral guide is used alternately by both sides. The section link (23 mm) **(A)** is used in combination with the lateral guide holder (23 mm) **(B)** as a spacer between the sections.

- The use of a section transfer, diverter, or junction requires parallel section spacing of 23 mm

Material:

- A, B: non-rusting steel
- Fastening parts: Galvanized steel

Ordering codes

		No.
Section link	10	3842532998
Lateral guide holder	10	3842532980