


Protective Covers for ST 5/XH, ST 5/H



- section center protective cover **(A)**
- Protective covers for transition between curve (diverter, junction) / conveyor unit **(B)**
- Protective covers for transition between conveyor unit/conveyor unit with different rollers **(C)**
- Spring element **(H)**, 4x required for each protective cover

- Spring element
- Spring element **(H)**, 2x required for each end plate

Product description


Conveyor unit selection

Technical data

No.	Material
3842545404	Galvanized steel
3842545609	
3842545405	Galvanized steel
3842545360	
3842545612	Galvanized steel
3842545361	
3842545362	Galvanized steel
3842545363	
3842545403	Galvanized steel
3842545638	
3842545641	Galvanized steel
3842545365	
3842545482	Galvanized steel
3842545617	
3842545483	Galvanized steel
3842545485	
3842545621	Galvanized steel
3842545484	
3842545506	Galvanized steel
3842545507	
3842545508	Galvanized steel
3842545616	
3842545619	Galvanized steel
3842545644	
3842545628	Galvanized steel
3842545629	
3842545645	Galvanized steel
3842545640	
3842545364	Galvanized steel
3842545214	

Ordering codes

Protective Covers for ST 5/XH, ST 5/H



	b ¹⁾	p ²⁾	p1/p2	p2/p3		No.
	mm	mm	mm	mm		
Protective covers for ST 5/XH, ST 5/H 455/130	455	130				3842545404
Protective covers for ST 5/XH, ST 5/H 455/195	455	195				3842545609
Protective covers for ST 5/XH, ST 5/H 650/130	650	130				3842545405
Protective covers for ST 5/XH, ST 5/H 650/195	650	195				3842545360

	b ¹⁾	p ²⁾	p1/p2	p2/p3		No.
	mm	mm	mm	mm		
Protective covers for ST 5/XH, ST 5/H 650/260	650	260				3842545612
Protective covers for ST 5/XH, ST 5/H 845/130	845	130				3842545361
Protective covers for ST 5/XH, ST 5/H 845/195	845	195				3842545362
Protective covers for ST 5/XH, ST 5/H 845/260	845	260				3842545363
Protective covers for ST 5/XH, ST 5/H 845/325	845	325				3842545403
Protective covers for ST 5/XH, ST 5/H 1040/130	1040	130				3842545638
Protective covers for ST 5/XH, ST 5/H 1040/195	1040	195				3842545641
Protective covers for ST 5/XH, ST 5/H 1040/260	1040	260				3842545365

	b ¹⁾	p ²⁾	p1/p2	p2/p3		No.
	mm	mm	mm	mm		
Protective cover for ST 5/XH, ST 5/H b=455 p1/p2=130/130	455		130/130 ³⁾			3842545482
Protective cover for ST 5/XH, ST 5/H b=455 p1/p2=130/195	455		130/195 ³⁾			3842545617
Protective cover for ST 5/XH, ST 5/H b=650 p1/p2=130/130	650		130/130 ³⁾			3842545483
Protective cover for ST 5/XH, ST 5/H b=650 p1/p2=130/195	650		130/195 ³⁾			3842545485
Protective cover for ST 5/XH, ST 5/H b=650 p1/p2=130/260	650		130/260 ³⁾			3842545621
Protective cover for ST 5/XH, ST 5/H b=845 p1/p2=130/130	845		130/130 ³⁾			3842545484

	b ¹⁾	p ²⁾	p1/p2	p2/p3		No.
	mm	mm	mm	mm		
Protective cover for ST 5/XH, ST 5/H b=845 p1/p2=130/195	845		130/195 ³⁾			3842545506
Protective cover for ST 5/XH, ST 5/H b=845 p1/p2=130/260	845		130/260 ³⁾			3842545507
Protective cover for ST 5/XH, ST 5/H b=845 p1/p2=130/325	845		130/325 ³⁾			3842545508
Protective cover for ST 5/XH, ST 5/H b=455 p2/p3=130/195	455			130/195 ⁴⁾		3842545616
Protective cover for ST 5/XH, ST 5/H b=650 p2/p3=130/195	650			130/195 ⁴⁾		3842545619
Protective cover for ST 5/XH, ST 5/H b=650 p2/p3=195/260	650			195/260 ⁴⁾		3842545644

	b ¹⁾	p ²⁾	p1/p2	p2/p3		No.
	mm	mm	mm	mm		
Protective cover for ST 5/XH, ST 5/H b=845 p2/p3=130/195	845			130/195 ⁴⁾		3842545628
Protective cover for ST 5/XH, ST 5/H b=845 p2/p3=195/260	845			195/260 ⁴⁾		3842545629
Protective cover for ST 5/XH, ST 5/H b=845 p2/p3=260/325	845			260/325 ⁴⁾		3842545645
Protective cover for ST 5/XH, ST 5/H b=1040 p2/p3=130/195	1040			130/195 ⁴⁾		3842545640
Protective cover for ST 5/XH, ST 5/H 1040/130	1040	130		195/260 ⁴⁾		3842545364
Spring element					50	3842545214

1) b = track width

2) p = roller spacing

3) p1/p2 = Transition between different roller spacing dimensions

4) p2/p3 = Transition between different roller spacing dimensions